

MPK-WF

Marine pack

Take your Cyber-shot with you on your underwater journeys. Dive down to 132 feet and take spectacular photos and movies.



Bullets

- Take amazing underwater shots up to 132 feet (40m) deep
- Works with the underwater photo mode of your Cyber-shot® camera
- Takes advantage of the underwater movie mode of the Cyber-shot® DSC-W350 camera
- Basic camera functions available while in use
- LCD hood and hand strap included

Features

Dive Down

Take amazing underwater shots up to 132 feet (40m) deep

Photo Mode

Works with the underwater photo mode of your Cyber-shot® camera

Movie Mode

Takes advantage of the underwater movie mode of DSC-W350 Cyber-shot® camera

Basic Camera Functions

Basic camera functions available while in use

Hood and Hand Strap

LCD hood and hand strap included

Specifications

Weights and Measurements	
Depth (Approx.)	Up to 132 ft(40m)
Dimensions (Approx.)	
Dimensions (Approx.)	5 7/8 x 4 1/2 x 3 5/8in (148mm x 112mm x 89mm)
Weights and Measurements	
Weight (Approx.)	1 lb 1oz (480g)
General	
Function	ON/OFF (Power), Shutter, Playback, Zoom(W/T), Mode, Home, Menu, Disp, Flash, Self-timer, Enter
Material	Plastic and glass
Operating Conditions	
Storage Temperature	-4 to +140°F(-20 to +60°C)

Water Resistance	O-ring, buckle
Hardware	
Microphone	No
Accessories	

Supplied Accessories	Hand strap
	LCD hood
	Diffuser
	Front attachment F-C (for DSC-W330)
	Front attachment F-D (for DSC-W350)
	Rear attachment R-B (for DSC-W350, W330)
	Grease
	O-ring
	Spacer
	O-ring
	Maintenance Manual
	LCD spacer (for DSC-W350)
	Reflex prevention ring

